



#### Installation Instruction:

- 1.Screw out the screws under head and remove the rear box
- 2.Connect wires correctly to power
- 3.Fix the rear box into cutout hole
- 4.Match lamp body to rear box and fix the screws under head

#### Caution !

Input: 110V-265V,50/60Hz

- 1.Power must be off before installation.
- 2.Installation/Repair only by authorised persons.

#### Wire Connection

